

Bambino

Setup Instructions

1. Take the aluminum pipes out and assemble.
2. Fit the pole to the base by sliding it on.
3. Now place the graphic over the aluminum pipes and stretch to the base.
4. Wrap the graphic under the base and feed the silicone into the groove.

